Nominal element spacing for *ECOFLOOR* elements

Produc	t code >>>>	02-120225	02-120350	02-120525	02-120700	02-120875	02-121000		02-122200	02-121800	02-121450	02-121250	<<<<
Watts	Zone size	225W	350W	525W	700W	875W	1000W		2200W	1800W	1450W	1250W	Zone size
Length	SQM	16.8	28.9	39.2	54.8	65	83		175	150	118	100	SQM
	1.0	55										54	5.8
	1.1	61										56	6.0
	1.2	66				LECEND						58	6.2
	1.3	72 77				LEGEND						59 61	6.4
	1.5	83					element laid dire	ect to				63	6.8
	1.6	88	51				concrete slab or					65	7.0
	1.7	94	55				substrate	.,,,			57	67	7.2
	1.8	99	58								58	69	7.4
	1.9		61				Recommended t	that the			60	70	7.6
	2.0		element is laid on F-Board				n F-Board			61	72	7.8	
	2.1		67 under tile insulation board						63	74	8.0		
	2.2		71					1		•	64	76	8.2
	2.3		74								66	78	8.4
	2.4		77 80	F0							68	80	8.6
	2.5		83	59 62						56	69 71	82 83	9.0
	2.7		87	64						57	72	85	9.2
	2.8		90	66						58	74	87	9.4
	2.9			69						59	75	89	9.6
	3.0			71						61	77		9.8
	3.2			76						62	79		10.0
	3.4			80	58					63	80		10.2
	3.6			85	61					64	82		10.4
	3.8			90	64					66	83		10.6
	4.0			95	68					67	85		10.8
	4.2			99	71	60			58	68	86		11.0
	4.4				74 78	63			59 60	69 70	88 90		11.2 11.4
	4.8				81	68			61	70	91		11.6
	5.0				85	71	56	-	63	73	93		11.8
	5.2				88	74	58		64	74	94		12.0
	5.4				91	77	60		65	75		•	12.2
	5.6				95	80	63		66	77			12.4
	5.8					83	65		67	78			12.6
	6.0					86	67		68	79			12.8
	6.2					88	69		69	80			13.0
	6.4					91	72	-	70	82			13.2
	6.6					94 97	74 76		71 72	83 84			13.4 13.6
	7.0					100	78		73	85			13.8
	7.2						80		74	87			14.0
	7.4						83	[75	88			14.2
	7.6						85		76	89			14.4
									77	90			14.6
									78	92			14.8
									80	93			15.0
NOTE: 1		7.25% has been				. 15			81	94			15.2
	element spa	cing to account	tor a wall perif	neter stand-on	or Summ (typi	icai).			82 83				15.4
NOTE: 2	The element	spacings in the	e orange and hi	ue columns are	e a general guir	deline only and			84				15.6 15.8
								85				16.0	
1 May vary on a case by case basis due to shape form in variations of the floor area.													16.2
NOTE: 3													16.4
													16.6
HOW TO READ THIS TABLE 89													16.8
·									90				17.0
STEP 2 If you ARE NOT using F Board, scan across to the nearest ORANGE column. 91													17.2
								92				17.4	
									93				17.6